

Welcome

1. Safety First

IMPORTANT

1.1 Before Mowing

1.2 When Mowing

1.3 Safe Usage

1.4 Symbols and Decals

1.5 Environmental Protection

2. About Your Anker eufy Robot Lawn Mower

2.1 What's in the Box

2.2 Overview

2.3 How Anker eufy Robot Lawn Mower Works

2.4 Specifications

3. Getting Started

3.1 Connect the App

3.2 Start Your First Mowing

3.3 Work Zone Settings

4. Daily Use

4.1 Panel Operations

4.2 Light Indicators

4.3 Mow

5. Maintenance

5.1 Keep It Clean

5.2 Replace Cutting Blades

5.3 Transportation

5.4 Battery

5.5 Power Supply

5.6 Storage

5.7 Recycling and EOL Disposal

5.8 Other

6. Limited Warranty

7. Important Information

7.1 Trademark and Legal Statement

7.2 Notice

Welcome

Thank you for choosing the Anker eufy robot lawn mower for your garden care needs.

Anker eufy robot lawn mower is ready to go with a simple one-step setup. Say goodbye to perimeter wires, intricate RTK setup and difficult-to-operate manual lawn mapping.

Powered by the cutting-edge Anker eufy V-FSD AI vision system, Anker eufy mows as smartly as a human.

This user manual will help you learn and operate Anker eufy robot lawn mower. Please enjoy the fun of care-free mowing and a perfectly maintained lawn!

Intended use

This product is strictly intended for domestic lawn mowing only. Using the mower for any other purpose is prohibited and may lead to serious injury. It is essential to read and understand all warnings and precautions in this manual to reduce risks. While following the instructions can lower the chance of accidents, some risks are inherent and cannot be completely eliminated. The operator or user is responsible for any incidents involving others on their property while operating the mower.

1. Safety First

IMPORTANT

READ CAREFULLY BEFORE USE - KEEP FOR FUTURE REFERENCE

Your safety is our priority. Before using the product, please read the following important safety guidelines to ensure a safe and enjoyable experience.

The safety rules aim to draw your attention to potential dangers. The safety symbols, and their explanations, require your careful attention and understanding. The safety warnings do not, by themselves, eliminate any danger. The instructions or warnings they provide are not substitutes for proper accident prevention measures.

WARNING: Read all safety warnings and instructions. Make sure you understand the instructions and are familiar with the controls and proper use of the appliance. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury. Carefully read the instructions for the safe operation of the appliance. Save all warnings and instructions for future reference.

WARNING: Failure to obey a safety warning can result in serious injury to yourself or others. Always follow safety precautions to reduce the risk of fire, electric shock and personal injury. Save the owner's manual and review it frequently to continue safe operation and instruct others who may use this tool.

WARNING: This machine produces an electromagnetic field during operation. This field may under some circumstances interfere with active or passive medical implants. To reduce the risk of serious or fatal injury, we recommend that persons with medical implants consult their physician and the medical implant manufacturer before operating this machine.

NOTE: The term "appliance" encompasses the mower, the base station, and all components, accessories, and equipment related to this product.

- Read the instructions carefully. Be familiar with the controls and the proper use of the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Users should be between the ages of 18 and 70. Local regulations may restrict the operator's age. Children should be supervised to ensure they do not play with the appliance.
- Make sure to set up and use the mower and the base station according to the guidelines. For the full User Manual and up-to-date information, please visit eufy.com.
- Using the appliance for purposes other than mowing can cause serious injury. To avoid injuries, please read and understand all the warnings and cautions. You can reduce the risk by following the instructions and warnings in this manual, but you cannot eliminate all risks. The operator or user is responsible for accidents or hazards occurring to other people on their property.

- The mower has many built-in safety sensors; however, safety risks still exist. Set a mowing time when no people or pets on the lawn. Inform the neighbors about the risks of accidents or hazards. When using the mower on a public lawn, or when your lawn is open to your neighbor or street, protect or fence the lawn, or put up a warning sign around the working area that says: **WARNING! Automatic lawn mower! Keep away from the machine! Supervise children!**
- DO NOT attempt to modify this appliance on your own. Alterations could disrupt its functions, leading to serious injuries and/or damage, or invalidate the Limited Warranty.
- Only use parts and accessories approved by Anker eufy's manufacturer.
- Please ensure you receive the proper training before using the appliance. Never let individuals who are not familiar with this appliance, or children operate it. Ensure that only those who understand how the mower works and behaves are allowed to use it.
- The mower contains batteries that can only be replaced by the manufacturer or authorized service personnel.
- To recharge the mower, only use the base station.
- Seek medical advice immediately if any cell of this appliance has been swallowed.
- To prevent potential damage, ensure the mower operates at least 1 meter (3') away from sprinkler heads. Do not use the mower and sprinklers at the same time. Schedule the mower to operate at a different time from the sprinklers.
- Be careful when adjusting the machine to prevent fingers from entangling moving blades and fixed parts of the machine.
- Replace worn or damaged parts for safety; Use only genuine replacement parts and accessories. Where parts are consumable, the spare part shall be clearly identified, e.g. by using a part number or other means.

1.1 Before Mowing

- Ensure the correct installation of the automatic perimeter delineation system as instructed.
- On multi-spindle appliances, take care, as rotating one blade may cause the other blades to rotate.
- Avoid operating the equipment in wet grass, where feasible.
- Do not operate the appliance or its peripherals if guards or shields are damaged, or if the cord is frayed or worn out.
- Do not use the mower if the blade disc, body, blades, screws, nuts, or cables are damaged.
- Be careful with sharp objects in this product, like screws and stakes. Do not point them towards people or animals.
- For optimal mowing performance, we recommend mowing in dry conditions. Mowing in the rain can cause grass to clump on the mower, and the mower may slip. Avoid mowing in adverse weather conditions, including heavy rain, thunderstorms, or snow.
- Regularly check that all parts of the mower are working properly.
- Regularly check to ensure the blades, blade screws, and the cutting assembly are not worn or damaged. If they are, replace the blades and screws in sets to maintain balance. Be cautious with multi-spindle models, as turning one blade may cause others to rotate as well.
- Thoroughly inspect the area where the equipment is to be used and remove all objects which can be thrown by the machine.
- Regularly check the area where the mower will be used and clear away stones, sticks, wires, bones, and other foreign objects. The Limited Warranty does not cover damage caused by objects left on the lawn.

1.2 When Mowing

- Children should not be allowed to be near or play with the machine when it is operating.
- Start the mower as directed in the manual. When powering on, ensure your hands and feet are clear of the rotating blades. Avoid placing hands or feet near or under any moving parts and blades. Always stay away from the discharge opening. Never position your hands or feet close to or under the mower when it is running.

- Never pick up or carry the mower when the motor is running. Avoid lifting the mower during operation. Sitting or riding on the mower or the base station is strictly prohibited. Additionally, do not place any objects on top of the mower or the base station.
- Switch off the mower:
 - Before removing a blockage.
 - Before inspecting, cleaning, or performing maintenance on the mower.
- Always switch off the mower when it is not in use. The mower can only be started when its power is switched on.
- Do not touch moving parts until they have completely stopped.
- Do not let the mower operate unsupervised if you are aware of pets, children, or people nearby.
- Be cautious of flying objects! Maintain a safe distance from the mower when it is operating.
- Avoid overreaching. Always keep your balance and make sure your footing is secure on slopes. Walk—do not run—while using the mower or its accessories. Do not mow on slopes that are steeper than the maximum incline specified for the operating area, including the boundary.
- If the mower emits an unusual sound or triggers an alarm, immediately press the STOP button.
- If the machine starts to vibrate abnormally, check for damage before restarting.
- Should you experience unusual vibrations, switch off the mower, place it on flat ground for about 30 seconds, and then restart it. If the problem continues, reach out to the authorized after-sales service.

1.3 Safe Usage

Do not use the mower outside the temperature range of 5°C to 45°C (41°F to 113°F). Operating it in low or high temperatures can reduce its performance and may cause accidents.

Maintenance and storage

WARNING: Always switch off the power when the mower is flipped upside down. The power should also be switched off when performing any maintenance on the mower's underside, including cleaning or changing blades.

- It is recommended that an adult perform regular maintenance on the mower (please refer to “[5. Maintenance](#)”).
- Regularly inspect the warning devices to ensure their effectiveness. These include the buzzer, the LED light on the base station, and the mower's ambient light.
- Keep all nuts, bolts, and screws tightly secured to ensure the appliance is in a safe working condition.
- Check the mower each week for worn or damaged parts and replace them as necessary for safety.
- Pay close attention to the blades and blade disc to ensure they are not damaged. If necessary, replace all blades and screws simultaneously to maintain balance in the rotating parts.
- Follow the manufacturer's instructions for appliance maintenance.
- Wear protective gloves when replacing blades to prevent injuries.

Charging and Battery Safety

- If under extreme conditions, any electrolyte should escape from the battery, avoiding contact with skin. If the electrolyte does come into contact with your skin, rinse it off with water and consult a doctor. In the event of electrolyte contact with your eyes, it's essential to consult a doctor.
- Keep moisture, rain, or splashed water away from the charging location.
- The ambient temperature must not exceed 45°C (113°F). Never expose the device to direct sunlight or excessive heat.
- Batteries that are defective or damaged or can no longer be recharged, must be disposed of as hazardous waste. Hand them over at a special collection point. Never harm our environment. Do not dispose of unusable batteries in domestic waste, fire, or water.
- Only use the battery produced by the original manufacturer.

- Do not throw Li-ion batteries into water or fire, risk of explosion!
- Protect the battery from impacts, and do not open it.
- Never discharge the battery completely and recharge it occasionally if not used for a prolonged period. If the battery has not been used for over 6 months, it is advisable to recharge it.
- Do not repair or perform any manipulation on the battery pack. These actions should only be carried out by after-sales or manufacturer-appointed technicians.
- Incorrect charging may lead to electric shock, overheating, or leakage of corrosive liquid.
- If the cord of the power supply or the extension cable is damaged or entangled, disconnect the power supply from the socket and then untangle it. For safety, always pull from the plug body, not the cord, when disconnecting from the socket. If the cord is damaged, contact after-sales service for professional repair or replacement.
- Connect the base station and/or its peripherals only to a supply circuit that is protected by a Residual Current Device (RCD) with a tripping current not exceeding 30 mA.
- During charging, use the charger specified for this battery.
- Do not dismantle, open, or shred battery cells. Avoid short-circuiting the battery as it may cause burns or a fire. Do not expose the battery to mechanical shock.
- Always follow the instructions and use the correct charging process. The battery should not be charged independently and must only be charged when installed in the Anker eufy mower. Use only the Anker eufy base station and the provided adapter for charging. Incorrect use can lead to electric shock, overheating, or battery leakage.

Safe Transport

- For transportation over long distances, use the original packaging for the base station and the mower.
- To safely move the appliance:
 - Press the STOP button to stop the mower.
 - Always turn the mower off before lifting or carrying it
 - Lift the mower by its handle.
 - When carrying the mower, keep the blade disc pointed away from your body.

1.4 Symbols and Decals

Symbols and Decals

Symbol	Description
	WARNING - Read user instructions before operating the machine
	WARNING - Keep a safe distance from the machine when operating
	WARNING - Operate the disabling device before working on or lifting the machine
	WARNING - Do not ride on the machine
	WARNING - It is not permitted to dispose of this product as normal household waste. Ensure that the product is recycled in accordance with local legal requirements


Symbol	Description
	This product conforms to the applicable EC Directives
	Warning
	Class II appliance
	Class III appliance
 Li-ion	Li-ion battery. This product has been marked with a symbol relating to 'separate collection' for all battery packs and battery pack. It will then be recycled or dismantled in order to reduce the impact on the environment. Battery packs can be hazardous for the environment and for human health since they contain hazardous substances
IPX6	IPX6 for base station
IPX6	IPX6 for robotic lawn mower
	Direct current
	Alternating current
	This item can be recycled
	This product is fragile
	This way up
	Keep away from sunlight
	Keep the pack of this product dry
	Do not roll

1.5 Environmental Protection


	Do not dispose of electrical products with household trash. Please recycle where possible. Contact your local waste authority or the place of purchase for recycling guidance.
---	--

2. About Your Anker eufy Robot Lawn Mower


2.1 What's in the Box




Lawn Mower




Base Station



Garage



Power Adapter



Blade Kit




Grease

2.2 Overview


Top View

The picture is for reference only.



Bottom View


The picture is for reference only.



This slot is solely for placing an AirTag (sold separately). The Anker eufy app does not work with AirTags. For real-time location information of your mower, we also recommend you subscribe to our data plans. Contact Anker eufy Support for details.

Base Station

The picture is for reference only.



2.3 How Anker eufy Robot Lawn Mower Works

Anker eufy robot lawn mower comes with our V-FSD visual perception system that empowers it to operate autonomously.

- This system can distinguish between grass-covered areas and other surfaces to ensure that the robot does not stray beyond the boundaries of the lawn.
- This system utilizes visual positioning technology, enabling functions such as robot navigation, systematic cutting, and returning to the base station.

Functions

Boundary Management

No perimeter wire or RTK reference station installation, no manual guided mapping. With V-FSD visual perception technology, Anker eufy knows where the boundary is.

Systematic Cutting

Anker eufy robot lawn mower, equipped with an advanced visual positioning system, achieves back-and-forth systematic cutting. The mower's cutting path is seamlessly displayed on the accompanying app, allowing users to monitor the progress visually. With a single job initiation, Anker eufy can complete a full coverage cut.

Obstacle Avoidance

Anker eufy detects objects ahead in real time using its stereo vision technology and image segmentation technology. Non-grass obstacles, such as tree stumps, balls, pets, and children's toys, will be avoided without collision.

Cutting Height

Before using your Anker eufy robot lawn mower for the first time, make sure that the grass height on your lawn is no more than 9 cm (3.5 in). If you want to drastically shorten the height of your grass, it is recommended that you do so gradually over time, cutting no more than one-third of the grass length at one time, by adjusting the cutting height in steps. You can adjust the cutting height through the app.

Charging the Mower

When your mower needs to recharge its battery, it will stop mowing and navigate back to the base station. Once charging is completed, the mower will automatically return to the exact spot where mowing was interrupted before recharging, and then resume mowing.

Multi-base Mode

If you have a separate lawn larger than 1000 square meters (0.25 acre) that the robot cannot reach from its existing base station, you can utilize the Multi-base Mode. As each Anker eufy base station has a unique ID, to use Multi-base Mode, you will need to purchase an additional Anker eufy base station. Once the new base station is set up on the second lawn and the mower is placed inside the base station, it will automatically recognize the new base station*. Upon starting the mower, it will create another new map for that lawn. When the mower is moved to a different base station, it will load the corresponding map and any No-go Zone configurations.

Schedule

You can set your mowing schedule through the app. This feature allows you to set a unique mowing schedule for each day of the week.

Rain Sensor and Rain Delay

Anker eufy robot lawn mower is designed to be weather-resistant. But mowing wet grass may not yield optimal results. The mower is equipped with a rain sensor which detects rain and prompts the mower to stop mowing and go back to its base station. When the grass is dry, the mower resumes mowing.

Cellular Data

The cellular data provides support for information transmission when the Wi-Fi signal is weak. Additionally, a cellular network is required for the anti-theft function - while the mower is powered on, it can send out GPS location information. Different cellular data plans (sold separately)* are available in the app. Contact Anker eufy Support for details.

* If you need to purchase a data plan or an additional base station, contact Anker eufy Support for details.

2.4 Specifications

		E15 Gen2 (T280L)
Recommended Mowing Area		1000 m ² (0.25 Acre)
Cutting Height		25 to 75 mm (1 to 3 in)
Cutting Width		203 mm (8 in)
Maximum Slope		18° (40%)
Over-the-air Update (OTA)		App, Firmware
Robot Mower Dimensions Length × Width × Height		60.3 × 39.4 × 31.8 cm (23.7 × 15.5 × 12.5 in)
Base Station Dimensions Length × Width × Height		72.7 × 48 × 45.2 cm (28.6 × 18.9 × 17.8 in) Without Garage Height: 39.8 cm (15.7 in)
Weight		Robot Mower: 11.6 kg (26 lbs) Base Station: 5.9 kg (13 lbs)
Waterproof (IP rating)		Robot Mower: IPX6 Base Station: IPX6
Working Voltage		24 Vdc
Capacity of Battery		93.24 Wh
Charging Time		90 to 110 min
Mowing Time on One Full Charge		90 to 110 min
Recommended Operating Temperature		0 to 45°C (32°F to 113°F)
Measured Sound Power Level LWA		66.30 dB
Sound Power Uncertainties KWA		3 dB
Sound pressure Level LpA		56.0 dB
Sound pressure Uncertainties KpA		3 dB
GPS Module Accuracy For Anti-Theft Tracking		20 m to 30 m (65.6 ft to 98.4 ft)
IoT Connectivity	Wi-Fi	2400.0 - 2483.5 MHz / 5150 - 5250 MHz / 5735 - 5835 MHz
	Cellular Network	LTE-FDD: B1/B2/B3/B4/B5/B7/B8/B12/B13/B20/B25/B26/B28/B66 LTE-TDD: B38/B40/B41
Power Adapter & Battery Pack	Power Adapter	Model: RKPO-UL3002000DP-6 (US); RKPO-DE3002000DP-6 (EU); RKPO-AU3002000DP-6 (AU); RKPO-UK3002000DP-6 (UK); RKPO-SW3002000DP-6 (SW). Input: 100-240Vac, 1.3A ,50/60 Hz; Output: 30Vdc, 2A
	Battery Pack	Model: C0914K8; Rating: 22.2Vdc, 4200 mAh

3. Getting Started

3.1 Connect the App


To enjoy all the available features, it is recommended to control your lawn mower via the Anker eufy app.

Before you start, make sure:


- Your smartphone is running iOS 11.0 (or above) or Android 8.0 (or above).
 - The 2.4GHz band wireless signal is enabled on your wireless router.
1. Download and install the [Anker eufy app](#) from the App Store (iOS devices) or Google Play (Android devices).



2. Open the app, create a new account or log into your own account.



3. Tap + > Add Device > Clean > Robot Lawn Mower > Robot Lawn Mower E15 Gen2 to connect the mower.



4. Follow the in-app instructions to complete the setup.
- After connecting successfully, you can control the lawn mower via the app.
 - With the app, you can start / pause mowing, schedule mowing, view the operation status, receive notifications, set up "No-go" zones, and access additional features. For detailed instructions, refer to the in-app operation guide.

3.2 Start Your First Mowing

Place the mower on the base station. Make sure the green indicator on the panel is on.


To begin mowing, press  and then  on the panel.

When the mower is used for the first time, it will automatically perform an auto-mapping task. This process may take several hours, depending on the environment and the size of the lawn. If the battery runs low during auto-mapping, the mower will automatically return to the base station to recharge and resume the task once fully charged.

If there are multiple non-adjacent lawn areas, follow the instructions in the "Work Zone Settings" section for "Pathway" function after the first area has been mapped. Use the app to remotely guide the mower to the next lawn area, where it will continue mapping automatically.

3.3 Work Zone Settings

In the Anker eufy app, tap **Edit Map** > **No-go Zone** / **Must-Mow Zone** / **No-Mow Zone** to set up customized mowing areas based on your lawn conditions and needs.



No-go Zone

Before starting auto-mapping for the first time, it is recommended to set up a No-go Zone and Virtual Fence in the app to prevent the mower from entering restricted areas. The following scenarios require these settings:

- Water edges, such as ponds and swimming pools, especially where there is no clear boundary between the lawn and the water.
- Steps or cliffs more than 3 cm (1.2 in) high.
- Small obstacles, such as clotheslines, tent ropes, or water pipes.
- Low flowerbeds, especially those lower than 20 cm (7.9 in) high, that the mower may drive over.
- Valuable plants or crops.
- Areas where you do not want the mower to go.
- Areas where mowing may cause danger or damage.
- Areas that are difficult for the mower to pass through or where it may get stuck frequently.
- Transparent objects, such as mosquito nets or glass doors.
- Ropes, such as tent lines.
- Irrigation equipment, such as water hoses or sprinklers.
- Electrical wires or devices.
- Pet houses.

Must-Mow Zone

Set a Must-Mow Zone to make sure the lawn mower prioritizes and covers specific areas that require regular mowing.

No-Mow Zone


Set a No-Mow Zone to exclude areas where mowing is not needed, such as decorative zones or temporarily restricted areas.

Pathway

If there are multiple non-adjacent lawn areas, tap **Pathway** and follow the in-app instructions to create a cross-zone pathway.

4. Daily Use


4.1 Panel Operations



Operation	Step Description
Power off	When the mower is powered on, press and hold  for 2 seconds. The mower will provide a voice prompt then shut down, and the indicator lights on the panel will turn off. The mower cannot be powered off while docked on the base station.
Power on	When the mower is powered off, press and hold  for 3 seconds to turn it on.
Start mowing	Press  and then  to confirm.
Auto-recharge	Press  and then  to confirm.
Pause	Press any button while the mower is operating.
Stop	Press  on the mower.
Activate/deactivate the child lock	Press and hold both  and  for 2 seconds.
Reset the Wi-Fi connection	Press and hold both  and  for 2 seconds.
Restore factory settings	Press and hold both  and  for 5 seconds.

4.2 Light Indicators

The mower is equipped with an LED light panel that contains five indicator lights. The diverse statuses of these lights inform you of the current status of the mower.



Light	State
Displays battery levels in white, turns yellow below 20%.	• Standby. • Paused. • Mowing. • Remote Control. • Mapping. • Processing data.
Displays battery levels in white breathing, turns yellow breathing below 20%.	• Returning to the base station. • Returning to the starting position.
Displays battery levels in white slow flashing, turns yellow slow flashing below 20%.	Waiting for Wi-Fi connection.
Red	Error.
Red flashes 3 times.	An error occurs.
Green	Charging.
White flashes fast for 1 second.	• Child lock activated/deactivated. • Saving map, please wait before proceeding.

Battery Level	LED Numbers
81%-100%	5
61%-80%	4
41%-60%	3
21%-40%	2
0%-20%	1


4.3 Mow

Start mowing

Before starting, make sure the lawn is properly prepared and the base station is correctly installed. Place the mower on the base station and confirm that it is charging. A green indicator on the panel confirms charging status.

After confirming, proceed to mow using one of the following methods:

- Start mapping and mowing through the app.
- Press  and then  to start mapping and mowing.




You can also set a mowing schedule in the app. The mower will start mowing automatically at the scheduled time.


Pause

To pause the mower during operation, use one of the following methods::

- Press any button on the panel.



- Press **STOP** on the mower.




- Pause the mower's operation through the app.

Resume mowing

To resume mowing when the mower is paused, use one of the following methods:

- Press **▶||** and then **✓** to continue working.




- Resume the mower's operation through the app.


Recharging the Mower

To return the mower to the base station for charging, use one of the following methods:

- Press  and then  on the mower. The mower will automatically return to the base station and begin charging.



- Start auto-recharge through the app.
- Manually carry the mower back to the base station.



5. Maintenance

To maintain optimal performance and extend the service life of your mower, clean it regularly and replace any worn parts.

Use a soft brush or cloth to clean the exterior of the mower thoroughly. DO NOT clean with alcohol, gasoline, acetone, or other corrosive/volatile solvents. These substances may damage the appearance and internal structure of the mower.


WARNING:

- Before maintenance, ensure that the mower is powered off.
- Wear protective gloves when handling or working near the blades.
- Always wear long trousers and work shoes when servicing the mower.
- The mower can only be maintained by adults.

5.1 Keep It Clean


Regularly clean the mower to remove dust, debris, and accumulated grass clippings.

DO NOT use a high-pressure washer to avoid damaging electronic or mechanical components.



Chassis and Blade Disc

If the chassis or blade disc is dirty, clean it with a brush or water hose. Remove any stuck debris promptly to prevent damage or cracking of the blade disc.




Driving Wheels

Remove mud or debris from the wheels for better traction.

Omni Wheel

Inspect and clean universal wheels regularly. If the wheels are stuck, clean off the debris. Apply the provided grease to the omni-wheel support after cleaning and once every month.




Rain Sensor

Check the rain sensor regularly and make sure the rain sensor is not covered by mud, grass clippings or other objects. You can either wash it or clean it with a soft brush. After cleaning, dry the rain sensor area.

V-FSD Cam Sensor

If the V-FSD Cam sensors are covered with dirt, use a lens cloth (sold separately) to gently wipe the sensor.

 **WARNING:** V-FSD is equipped with a precision camera. To avoid scratching, do not use any sharp or hard materials, such as a brush, to clean the sensor.




Base Station

To ensure proper docking, regularly inspect and clean the base station to remove any debris or mud. Make sure all connecting parts of the base station, the extension cable, and the power supply are not blocked.

Use a clean cloth to wipe the base station marker regularly.



WARNING: To avoid scratching, do not use any sharp or hard materials, such as a brush, to clean the base station marker.



5.2 Replace Cutting Blades

To ensure safe operation, replace worn or damaged blades. Additionally, regularly changing the blades helps achieve satisfactory mowing results and efficient energy use.

For regular use, it is recommended to replace the blades and screws every 1–2 months for safety and optimal mowing performance.





WARNING:

- Always wear protective gloves when replacing the blades.
- Use only the specified screws and blades approved by the manufacturer.
- DO NOT reuse screws. Used screws may wear out quickly, causing the blade to loosen, which can lead to serious injuries.
- To maintain a balanced cutting system, replace all 3 blades and screws simultaneously.


How to Replace the Blades

1. Gather the following items before starting.

 × 3 Screws	3 screws
 × 3 Blades	3 blades (Anker eufy SK5)
 Gloves	Gloves
 Cross-tip screwdriver	Cross-tip screwdriver (PH2)


2. Turn off the main switch.

 **WARNING:** Remember to power off the mower before operation.




3. Gently turn the mower over on a soft surface, then remove the screws and blades.

 **NOTE:** Be careful not to scratch the V-FSD Cam Sensor.





4. Install and ensure the new blades and screws are securely fastened (Torque: 1 N·m).

 **NOTE:** Before installing the new screws, it is recommended to position the blades as shown in the following figure on the left, to make the later installation step easier.




 **WARNING:** Do not hang the blade on the screw.





5. Check that the blades pivot freely. If not, loosen the corresponding screws and tighten them again.




5.3 Transportation

To safeguard your mower, use its original packaging for long-distance transport.

Always turn off the device before lifting, moving, or transporting it. Handle it gently to avoid damage from rough handling, such as throwing or applying excessive pressure.


Proper Lifting and Moving

Lift the mower using the handle, ensuring the blade disc is facing away from your body.



WARNING: Never lift or carry the mower while its motor is operating or rotating.

To prevent damage to the mower and/or the base station, do not lift the mower by the handle while it is docked at the base station. Always remove the mower from the base station before lifting it.



5.4 Battery

- Before storing, power off the mower and charge its battery to 85% or higher to prevent over-discharge and potential damage to the electrical components. For long-term storage, recharge the mower every 120 days (about 4 months).
- Battery damage caused by over-discharge will not be covered by the Limited Warranty.
- To maintain battery health, avoid extreme temperatures: do not use or store the battery below -20°C (-4°F) or above 50°C (122°F).
- The mower may experience significantly increased charging time and potentially shut down during mowing if the battery temperature is above 40°C (104°F) or below 5°C (41°F).

The battery life depends on how often the product is used and the total working hours. When the operation time is significantly shorter than usual per full charge or the lawn is not well-cut, consider contacting customer service or replacing the battery.

WARNING:

- Only use the battery produced by the original manufacturer. Each mower contains one battery pack.
- Do not use non-rechargeable batteries.
- Do not dismantle or puncture the battery casing. Keep away from metal objects to prevent short circuits. Keep away from fire, heat and direct sunlight.
- For information about battery and electrical waste, contact your household waste disposal service, your local or regional waste management office, or your point-of-sale.
- The battery compartment is not intended to be opened regularly. Only open the battery compartment when you need to change the battery.
- The battery pack contains electrolytes. If the electrolyte leakage comes into contact with your skin, wash off with soap and water immediately. Get medical help in case of eye contact and immediately flush the eyes with plenty of water for at least 15 minutes without rubbing.

5.5 Power Supply

Disconnect the power supply:

- Before clearing a blockage.
- Before checking, cleaning or working on the mower.
- After striking a foreign object to inspect the mower for damage.

Regularly examine the cord, plug, enclosure, and other parts. If any damage or signs of aging are found, stop using it immediately.



WARNING:

- **Do not use a damaged power supply:** Operate your equipment only with a fully intact power supply. If the power cord or plug is damaged, it must be replaced by the manufacturer, a service agent or the after-seller. This is crucial to prevent hazards. If the extension cord is found to be defective, replace it with a manufacturer-approved 10-meter cable.
- **Avoid connecting or touching damaged cords:** Never plug in a damaged cord or extension to the power outlet. Avoid touching a damaged cord or extension cable until it's safely unplugged from the socket. Damaged cords could expose you to live electrical parts, posing a danger.
- **Use only with the intended devices:** You must not use the power supply with any device or battery other than those specified by the manufacturer. Using it with other products can pose risks of injury, fires, or electric shocks. Only the original batteries are assured to be safe for use.
- **Do not charge a leaking battery:** Never attempt to charge your device if the battery is leaking. Doing so risks harm and equipment damage.
- Keep the extension cable away from moving hazardous parts to avoid damage to the cords which can lead to contact with live parts.
- During a thunderstorm threat, unplug the power supply from the outlet. Disconnect all cables and wires linked to the base station. Reconnect everything once the risk of thunder has passed.
- Connect the mower and/or its peripherals only to a supply circuit protected by a residual current device (RCD) with a tripping current of not more than 30 mA.

5.6 Storage

- Before storing, ensure the mower is powered off and its battery is charged to at least 85%. This prevents over-discharge that can lead to permanent damage.
- Store the mower in a cool, dry place indoors. Keeping it away from sunlight and extreme temperatures will help prevent the premature aging of components and potential battery damage.
- Keep the mower, the base station, and the power supply away from any heat sources like stoves or radiators, as well as chemicals. Ensure the power supply is protected from moisture and placed in a well-ventilated area.

5.7 Recycling and EOL Disposal

DO NOT treat the mower as domestic waste. For recycling information, contact your domestic waste service, your municipality, or point of sale.



WARNING: DO NOT dispose of the mower in a landfill, by incineration, or by mixing with household trash. Danger or serious injury can occur because of the electrical components.

5.8 Other

- The mower is continuously improved, and new software versions are provided free of charge. Be sure to keep your Anker eufy software up to date.
- Cellular data is used to send commands to the robotic lawn mower when Wi-Fi is unavailable and to transmit its location if the mower is stolen. A free trial data plan is included upon initial use of the mower. To continue using cellular data, renew the data plan within one month of initial activation. You will also need to renew the plan when the data allowance is used up or the service period expires. Renewal can be completed through the app.

6. Limited Warranty

Thank you for choosing Anker eufy. Below are the details of limited warranty service. Please read these terms carefully and register your product to enjoy full warranty benefits.

Anker Innovations Limited (hereinafter referred to as "Anker") guarantees that during the warranty period, this product will be repaired or replaced free of charge for any defects in materials or craftsmanship under normal usage, as long as the guidelines and instructions provided in our official documentation are followed. The official documentation includes, but is not limited to, the user manual, quick start guide, maintenance instructions, product specifications, disclaimers, and notifications within our app. This documentation may be available in multiple languages. In the event of any conflict, the latest English version on the official website shall prevail and control.

The following measures will be chosen by Anker for the warranty service:

- Replacement or repair of the defective parts, components or products. Replacement parts, components or products may not be new but will be in good working condition and carry the remaining warranty period of the original product. If the parts, components or products cannot be repaired under the conditions of no stock, off production or any other reasons, Anker will replace the product with a functionally equivalent model.
- Any parts, components, or products replaced during service or under warranty become the property of Anker.
- The warranty does not constitute additional claim rights.

Please be prepared to provide your original purchase receipt and the product's serial number, and make sure to upload your log files. If you wish to send your product for further diagnosis to a local service center or the Anker factory, you must arrange the shipping yourself. Should the issue be covered by the warranty, Anker will repair or replace the product and return it to you at no additional charge. If the problem is not covered by the warranty, Anker or the designated service center reserves the right to charge a fee for the service provided.

The limited warranty period varies for different products and components, as detailed in the table below:

Component	Limited Warranty Period
Robot lawn mower	2 years
Base station	2 years
Power adapter	2 years
Battery pack	2 years
Decoration / Appearance	No warranty
Cutting blade kit	No warranty
Other accessories	No warranty

Warranty Period Start Date

- The warranty period for the product starts from the date when the product is delivered.
- If you are unable to present an invoice or other acceptable proof of the purchase delivery date, Anker will first determine whether the first usage date recorded by the mower, such as the first mowing or first connection to Wi-Fi, can be used as the start date of the warranty period.
- If the first usage date is not accepted, the warranty will begin 90 days after the production date.
- This warranty period applies unless a different arrangement has been made between you and Anker.

Limited Warranty Eligibility

- Your product must be purchased from an authorized Anker dealer.
- You must provide the original purchase receipt.
- The serial number on your product must be legible, unobscured, untampered, and unmodified.
- All tamper-resistant seals must be intact, in place, and unmodified.

Limited Warranty Exclusions

The warranty does not cover the following:

- Claims made by third parties against you for damages.
- Products that have been modified without authorization.
- Damage caused by failure to follow the guidelines and instructions provided in our official documentation.
- Damage resulting from the use of improper attachments or parts not intended for the design.
- Damage caused by personal actions, foreign objects, or accidents.
- Damage caused by acts of nature or natural disasters, such as fire, flood, earthquake, lightning, or typhoons.
- Dissatisfaction on the product other than its quality, e.g. product color, outlook, shape.
- When configuring the parameters or behavior of the robot for the lawn perimeter and edges (including setting the edge cutting distance and pathways between lawns), the operation of the robot must be supervised. Please note that any damage to the robot caused by such settings, as well as any damage caused by the robot to people, furniture, pipes, wires, or other equipment during its operation, is beyond the scope of the warranty. Additional losses will not be compensated.
- Special, incidental, punitive, indirect, or consequential damages. This includes, but is not limited to, loss of profits, business revenue, goodwill, or anticipated savings. Loss, damage, or disclosure of your data.
- The warranty on the Cellular data module and its SIM card will not be valid under the following conditions:
 - The cellular network is not activated within 6 months of receiving the product.
 - The cellular data is not recharged within 6 months after the traffic or time is expired.

In any event, the total liability of Anker, its affiliates, suppliers, resellers, or service providers for damages from any cause is limited to the amount of actual direct damages, up to a maximum of the amount paid for the product.

Additional information

The warranty policy is subject to and governed by the latest English version available on the official website.

In case of any dispute, Anker Innovations Limited reserves the right for any final decision.

7. Important Information

7.1 Trademark and Legal Statement

Anker eufy is a registered trademark of Anker Innovations Limited, Android and Google Play are trademarks of Google LLC, and App Store is a service mark of Apple Inc. All trademarks mentioned in this manual are the property of their respective owners, retaining their trademark rights.

We have made every effort to include descriptions and instructions for all features of Anker eufy robot lawn mower E15 Gen2 in this printed material. However, due to ongoing product improvements and design changes, your Anker eufy robot lawn mower E15 Gen2 may differ slightly from what is displayed in this document. Please visit the Apple App Store (iOS) or Google Play Store (Android) to download and install the latest version of the Anker eufy application.

Please note that Anker eufy robot lawn mower E15 Gen2 comes in multiple models with varying features, and some features mentioned in this document may not apply to your device. The manufacturer reserves the right to change the design and functionality of Anker eufy products and documents without prior notice.

© 2026 Anker Innovations Limited. All rights reserved.

Anker eufy Legal Disclaimer

IMPORTANT: Users are required to agree to read the entire user manual and fully understand its contents (especially the sections related to safety warnings) before using this product, and comply with the instructions herein.

All damages resulting from misuse or failure to follow the user manual, including but not limited to the following circumstances, are the responsibility of the user:

1. Claims against you by third parties for injuries caused;
2. Damage to your product, loss, damage, or disclosure of data;
3. Special, incidental, punitive, indirect, or consequential damages, including but not limited to loss of profits, business revenue, goodwill, or anticipated savings.

Anker and its affiliates will not be liable for any related claims, liabilities, or losses.

In no event shall Anker, its affiliates, suppliers, distributors, or service providers be liable for damages from any cause exceeding the amount of actual direct damages, not to exceed the amount paid for the product.

1. Anker eufy robot lawn mower is an electric household product equipped with blades, which may pose risks to users, others, and nearby property. Users are required to thoroughly read the user manual and understand its contents, assuming all risks and losses associated with the product (especially those related to violations of safety warning instructions). Such risks include but are not limited to injuries, bodily harm, and/or property damage. If these consequences arise from the user assuming risks, Anker and its affiliated companies will not be held responsible for any related claims, liabilities, or losses.
2. This device is not suitable for individuals with weakened physical, sensory, or intellectual abilities (which may affect their ability to safely operate the product), or for those lacking experience and knowledge, including children, unless they have been supervised or instructed by a person responsible for their safety, and understand the instructions for using the equipment.
3. This device is designed for mowing lawns in open and level areas. Please use only equipment recommended by the manufacturer. Any other type of usage constitutes improper use.
4. Please review and comply with the laws or regulations governing this product in your local area. Users are responsible for ensuring that their use and/or disposal of the product within their jurisdiction complies with legal requirements.
5. Consumers should immediately inspect the product and its accessories upon receipt to ensure they are in good condition.

6. All individual components and parts of Anker eufy robot lawn mower must be installed correctly according to the user manual. Improper installation may lead to accidents. The mower may contain movable components and small parts. Please keep them out of reach of children to avoid choking hazards.

7. Please pay attention to the safety warnings listed in the user manual, including but not limited to:

WARNING: Incorrect usage of the product may pose hazards.

WARNING: Do not use the product when people, especially children or animals, are present in the working area.

WARNING: Keep hands and feet away from rotating blades. Never place hands or feet near or under the product when it is in operation.

WARNING: Seek medical assistance in case of injury or accident.

WARNING: Non-compliance with instructions in the user manual may result in injury or death to operators or bystanders.

WARNING: Failure to comply with instructions in the user manual may lead to product, material, or adjacent area damage.

WARNING: Always keep the mower within 6 meters of your position during operation, and avoid exceeding your line of sight.

WARNING: Do not mow while wearing open-toe sandals or barefoot.

WARNING: Do not attempt to charge the mower, power unit, base station, or power outlet if they are wet.

WARNING: Do not connect the power supply if the power cord or plug is damaged.

WARNING: Keep away from flammable or combustible materials while charging.

WARNING: Immediately stop charging and contact customer service upon detecting unusual odors, sounds, or light indications.

WARNING: Do not ride the mower or the base station.

WARNING: Do not touch rotating blades.

WARNING: Do not dispose of the product in a landfill, burn it, or mix it with household waste. Electronic components and batteries may pose serious hazards/injuries. For information on battery and electronic waste, please contact your household waste disposal service, local or regional waste management office, or your point of purchase.

8. This product contains battery components. Please adhere to the following safety handling and usage guidelines:

- **Only use the battery produced by the original manufacturer.** These batteries are essential for the device's operation and should not be tampered with.
- **Maintain the battery in a clean and dry condition.** Avoid exposure to moisture or contaminants that may affect their performance.
- **Avoid exposing battery to heat sources or flames.** Prolonged exposure to high temperatures can lead to damage or malfunction. Store battery away from direct sunlight.
- **Prevent short-circuiting of battery packs.** Store them securely and avoid contact with conductive materials that could cause unintended connections.
- **Do not dismantle or modify battery packs.** Alterations may result in hazardous situations or damage to the product.
- **Handle battery with care to prevent mechanical shock.** Rough handling can lead to internal damage or leakage.
- **In case of leakage, avoid skin or eye contact with battery fluids.** Rinse affected areas thoroughly with water and seek medical attention if necessary.

- **Seek immediate medical advice if any battery is swallowed.** Ingestion can lead to serious health complications.
- **Use only designated battery recommended for this device.** Incompatible batteries may pose safety risks or damage the equipment.
- **Keep battery out of reach of children.** Store them in a secure location inaccessible to young children.
- **Dispose of battery properly in accordance with local regulations.** Do not dispose of battery in regular household waste.

By adhering to these guidelines, you ensure safe usage and prolong the lifespan of your device. For any inquiries or assistance, please contact our customer support.

9. Users are not permitted to use any non-genuine accessories, and unauthorized disassembly or modification of the product is prohibited. You shall bear sole responsibility and risk for any damages, injuries, and property losses resulting from this. Anker shall not be liable for any claims, liabilities, and losses (or potential liabilities) arising from any harm, damage, or legal disputes caused by violations of the above terms, user inexperience, or failure to comply with the instructions in this manual.
10. Anker reserves the right to make changes to the product, release firmware updates, and update this manual at any time. Due to printing errors, inaccuracies in current information, or improvements to procedures and/or equipment necessary for the improvement of this user manual, Anker may make changes at any time without further notice. Such changes will be incorporated into new versions of this user manual. All illustrations are for reference only and may inaccurately depict actual equipment. Actual products and features may vary. Due to product updates, there may be some discrepancies in color, appearance, and other aspects between the products listed in this manual and the products you actually purchase. Please refer to the actual product.
11. This document should be considered a permanent part of the product and should be provided to the user along with the product at all times. Once again, thank you for choosing Anker eufy!

7.2 Notice

Information on Disposal for Users of Waste Electrical and Electronic Equipment



This symbol on the product or on its packaging indicates that used electrical and electronic products should not be mixed with unsorted municipal waste. For proper treatment, it is your responsibility to dispose of your waste equipment by arranging to return it to designated collection points.

Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling.

To return your used device, please use the return and collection systems or contact the retailer where the product was purchased, which is free of charge, please contact your local authority for further details of your nearest designated collection point.

Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

FCC COMPLIANCE NOTICE

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED RSS WARNING

The device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

ISED RADIATION EXPOSURE STATEMENT

This equipment complies with ISED RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator & your body.

EU DECLARATION OF CONFORMITY

This product complies with the radio interference requirements of the European Community.

Hereby, Anker Innovations Limited declares that the radio equipment type T280L is in compliance with all the related European Directives. The full text of the EU Declaration of Conformity is available at the following website: https://service.eufy.com/recommended?ref=Home_Page&type=Download.

UK PSTI STATEMENT

Hereby, Anker Innovations Limited declares that this device is in compliance with The Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023. For the Statement of Compliance, visit the website <https://www.eufy.com/uk/psti-related>.