





## Checking the Battery Level




1. Recharging
2. Trickle-Charging Mode
3. Remaining Battery Percentage

## Charging Your Devices


Charge your phones and tablets via the USB ports.






## Recharging Your Power Bank

Charge the power bank via the USB-C ports.




## Trickle-Charging Mode


1. Activate trickle-charging mode.



2. Charge your earbuds or other low-power devices using trickle-charging mode.



3. Exit trickle-charging mode.



Specifications

Total Cell Capacity	20,000 mAh
Input	USB-C1 / C2: 5V ≐ 3A / 9V ≐ 3A / 15V ≐ 2A / 20V ≐ 1.5A (30W max)
Output	USB-C1 / C2: 5V ≐ 3A / 9V ≐ 3A / 10V ≐ 2.25A / 12V ≐ 1.5A / 15V ≐ 2A / 20V ≐ 1.5A (30W max) USB-A: 5V ≐ 3A / 9V ≐ 2A / 12V ≐ 1.5A (18W max)
Total Output	5V ≐ 4.8A (24W max)