






Checking the Battery Level




1. Recharging
2. Trickle-Charging Mode
3. Remaining Battery Percentage

Charging Your Devices


Charge your phones and tablets via the USB ports.






Recharging Your Power Bank

Charge the power bank via the USB-C ports.




Trickle-Charging Mode


1. Activate trickle-charging mode.



2. Charge your earbuds or other low-power devices using trickle-charging mode.



3. Exit trickle-charging mode.



Specifications

Cell Capacity	10,000 mAh
Input	USB-C: 5V ≐ 3A / 9V ≐ 2.22A (20W Max)
Output	USB-C: 5V ≐ 3A / 9V ≐ 2.22A / 10V ≐ 2.25A (22.5W Max) USB-A: 5V ≐ 3A / 9V ≐ 2A / 10V ≐ 2.25A (22.5W Max)
Total Output	5V ≐ 3A (15W Max)