




Checking the Battery Level

Press the button to check the battery level.




Charging Your Devices

To charge a laptop, connect it to either USB-C port, or connect it to the USB-C 1 port when other ports are occupied.



Recharging Your Power Bank


Recharge your power bank via the USB-C 1 port.




Trickle-Charging Mode

A better way to charge your earphones


- ① Press the button twice to activate trickle-charging mode.



- ② Charge your earbuds or other lower-powered accessories.



③ Press once to exit trickle-charging mode.



Specifications

Cell Capacity	24000mAh (4800mAh x 5)
USB-C 1 Input	5V ≡ 3A / 9V ≡ 3A / 12V ≡ 1.5A / 15V ≡ 2A / 20V ≡ 1.5A
USB-C 1/USB-C 2 Output	5V ≡ 3A / 9V ≡ 3A / 12V ≡ 1.5A / 15V ≡ 3A / 20V ≡ 3.25A
USB-A Output	5V ≡ 3A / 9V ≡ 2A / 10V ≡ 2.25A / 12V ≡ 1.5A
USB-C1 + USB-C2 Output	65W Max
USB-C1 + USB-A Output	67.5W Max
USB-C2 + USB-A Output	15W Max
USB-C1 + USB-C2 + USB-A Output	60W Max
Total Output	67.5W Max