



At a Glance



|                            |                                |
|----------------------------|--------------------------------|
| 1. Power Button            | 2. USB-C Port                  |
| 3. Battery Level Indicator | 4. Wireless Charging Indicator |


Charging Your Phone or Earbuds Using a Charging Cable



| Status        | Wireless Charging Indicator | Battery Level Indicator           |
|---------------|-----------------------------|-----------------------------------|
| Charging      | Off                         | Showing the current battery level |
| Fully charged | Off                         | Off                               |


## Wireless Charging: for iPhone 12 Series or Later

To activate wireless charging, press the power button or place your phone on the power bank. The phone will be held in place magnetically and start charging.



| Status                      | Wireless Charging Indicator | Battery Level Indicator           |
|-----------------------------|-----------------------------|-----------------------------------|
| Wireless charging activated | Flashing white              | Showing the current battery level |
| Charging                    | Solid white                 | Showing the current battery level |
| Fully charged               | Solid white                 | Off                               |


## Recharging the Power Bank



| Status        | Wireless Charging Indicator | Battery Level Indicator           |
|---------------|-----------------------------|-----------------------------------|
| Charging      | Flashing white              | Showing the current battery level |
| Fully charged | Flashing white              | Off                               |

Note: When the temperature exceeds the operating limit, the battery level indicator will turn off. Let the power bank cool down before use.

Charging the Phone Wirelessly and Recharging the Power Bank Simultaneously



| Status                      | Wireless Charging Indicator | Battery Level Indicator           |
|-----------------------------|-----------------------------|-----------------------------------|
| Wireless charging activated | Flashing white              | Showing the current battery level |
| Charging                    | Solid white                 | Showing the current battery level |
| Fully charged               | Solid white                 | Off                               |

Specifications

|                 |                                 |
|-----------------|---------------------------------|
| Cell Capacity   | 5,000mAh 3.85Vdc / 19.25Wh      |
| USB-C Input     | 5V $\overline{\text{---}}$ 2.4A |
| USB-C Output    | 5V $\overline{\text{---}}$ 2.4A |
| Wireless Output | 5W / 7.5W                       |
| Total Output    | 12W                             |