

Checking the Battery Level

Press the power button to check the battery level.



- ① White Light: Battery Level Indicator
- 2 Blue Light: Wireless Charging Indicator
- 3 Power Button




*Note: In the recent period, power banks featuring either of the two logo versions shown above will be shipped randomly. Aside from the logo, the functionality of the products remains identical. Please be assured of the product's quality.

Charging Your Devices


Charging your devices wirelessly

The white battery level indicator and the blue wireless charging indicator will illuminate when your devices are being charged wirelessly.

Note: To manually activate or exit the wireless charging mode, press the power button twice.



Charging your devices via the Built-In USB-C Cable or USB-C Port




Note:


Use the built-in USB-C cable to achieve fast charging. Alternatively, enhance wireless charging speed by not using your phone and shutting down apps with high power consumption. When your device is charged via the built-in USB-C cable, wireless charging will be automatically disabled. Press the power button twice to reactivate wireless charging mode.

Recharging Your Power Bank

Recharge your power bank via the built-in USB-C cable or USB-C port.



Charging and Recharging Simultaneously



Specifications

Cell Capacity	10,000 mAh	
Input	USB-C Cable / USB-C Port: 5V = 3A / 9V = 2.22A / 12V = 1.66A (20W Max)	
Output	USB-C Cable / USB-C Port: 5V = 3A / 9V = 3A / 10V = 2.25A / 12V = 2.5A / 15V = 2A / 20V = 1.5A (30W Max)	
Wireless Output	5W / 7.5W	
Total Output	5V = 3A (15W Max)	

Korean SN Code Rules

Note: The 'x' of SN Code: xxxxxxxxxxxxxxx is a variable, see below table.

Variable 'x'	Range of variable	Content
Seventh	O-F	Denotes the hardware version which is not effected on the safety compliance.
Ninth and tenth	20,21,22,23,24	Denotes the year, 20 means 2020, 21 means 2021, 22 means 2022, 23 means 2023, 24 means 2024, and so on.
Eleventh and twelfth	01,02,03	Denotes weeks, 01 means the first week in this year, 02 means the secondary week in this year, and so on.
The last four	0001-FFFF	Denotes serial No.