



Checking the Battery Level

Press the button to check the battery level.




Charging Your Devices

Charge your phones and tablets via the USB ports.



Recharging Your Power Bank

Recharge the power bank via the USB-C port.




Trickle-Charging Mode


1. Press the button twice to activate trickle-charging mode.



2. Charge your earbuds or other low-power devices.



3. Press the button twice to exit trickle-charging mode.



Specifications

Cell Capacity	10000 mAh 3.7 Vdc / 37 Wh
PD Input	5V ≐ 2A
PD Output	5V ≐ 2.4A