



At a Glance



|   |                       |   |                     |
|---|-----------------------|---|---------------------|
| 1 | Power Button          | 5 | Play/Pause Button   |
| 2 | Power & Bluetooth LED | 6 | Volume Up Button    |
| 3 | Bluetooth Button      | 7 | USB-C Charging Port |
| 4 | Volume Down Button    |   |                     |


Charging Your Speaker

- Use a certified A-C cable and charger to prevent any damage.



|              |               |
|--------------|---------------|
| Flashing Red | Low Battery   |
| Steady Red   | Being Charged |
| Steady White | Fully Charged |

## Powering On / Off



|  |                                       |           |
|--|---------------------------------------|-----------|
|  | Press or Press and Hold for 2 Seconds | Power On  |
|  | Flashing White to Flashing Blue       |           |
|  | Press and Hold for 2 Seconds          | Power Off |
|  | Light Off                             |           |




This speaker will power off automatically after 20 minutes if no device is connected.

## Using Your Speaker

### Bluetooth Mode

Press the Bluetooth button to enter Bluetooth pairing mode, then select "**soundcore Select 4 Go**" from the Bluetooth list to connect.



|  |               |                              |
|--|---------------|------------------------------|
|  | Press         | Enter Bluetooth Pairing Mode |
|  | Flashing Blue | Bluetooth Pairing            |
|  | Steady Blue   | Bluetooth Connected          |




- If the speaker is not connected to a device within 3 minutes after being powered on, it will automatically exit Bluetooth pairing mode.
- To re-enter Bluetooth pairing mode, press the Bluetooth button once.
- This speaker can only play music on one mobile device at a time. If another connected device starts playing music, the speaker will automatically take over and interrupt the current playback without requiring the first device to pause.
- Each time you power on your speaker, it will automatically connect to your last connected device if available within the Bluetooth range. If not, press the Bluetooth button to enter Bluetooth pairing mode.

### True Wireless Stereo (TWS) Mode

Two identical soundcore speakers can pair with each other for stereo sound. Both speakers can play the same audio (one as the left channel and the other as the right channel).

With one speaker connected to a smartphone, press and hold the Bluetooth button for 2 seconds on two speakers to enter TWS pairing mode.



|  |                                                   |                        |
|--|---------------------------------------------------|------------------------|
|  | Press and Hold for 2 Seconds                      | Enter TWS Pairing Mode |
|  | Flashing White                                    | TWS Pairing            |
|  | Steady Blue (The Speaker Connected to Smartphone) | TWS Connected          |
|  | Steady White (The Other Speaker)                  |                        |

### Button Controls

|  |                                       |                               |
|--|---------------------------------------|-------------------------------|
|  | Press or Press and Hold for 2 Seconds | Power On                      |
|  | Press and Hold for 2 Seconds          | Power Off                     |
|  | Press                                 | Play / Pause                  |
|  | Press Twice                           | Next Track                    |
|  | Press Three Times                     | Previous Track                |
|  | Press                                 | Enter Bluetooth Pairing Mode  |
|  | Press and Hold for 2 Seconds          | Enter / Exit TWS Pairing Mode |
|  | Press                                 | Volume Up / Down              |

## soundcore App

Download the soundcore app to enhance your experience.



Google Play and the Google Play logo are trademarks of Google Inc.



Apple and the Apple logo are trademarks of Apple Inc.



**Product information:** Check the product name and software version, or read the user manual.

**Firmware update:** You will be informed once a new version of firmware is detected when you connect the speaker with the app.

**Battery status:** Indicates the remaining battery level of your speaker.

**Volume control:** Adjust the volume level via the app without pressing the buttons on the speaker.

**EQ settings:** There are various preset EQ settings you can choose from in the app to optimize your experience while enjoying different music genres.

- **soundcore Signature:** Standard EQ mode optimized for well-balanced sound.
- **Balanced:** No enhancement for high-frequency and low-frequency sounds.
- **Treble Boost:** High frequencies are enhanced.
- **Bass Boost:** Enhances low frequencies for a deeper, richer bass experience.

**Set Auto-power off time:** The speaker will automatically power off when time is up.

**Voice prompt:** Mute or restore the voice prompt while powering on/off.

## Reset

Press and hold the Bluetooth button and volume up button simultaneously for at least 8 seconds to reset the speaker.

## Specifications

Specifications are subject to change without notice.

|                                                     |                 |
|-----------------------------------------------------|-----------------|
| Power Input                                         | 5V = 1.5A       |
| Battery Capacity                                    | 2400mAh/3.65V   |
| Audio Output Power                                  | 5W              |
| Speaker Driver                                      | 1.75 Full Range |
| Charging Time                                       | 4H              |
| Playtime (varies by volume level and music content) | Up to 20H       |
| Waterproof Level                                    | IP67            |
| Bluetooth Version                                   | 5.4             |
| Bluetooth Range                                     | 30m / 98 ft     |

Hereby, Anker Innovations Limited declares that this device is in compliance with The Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023. For the Statement of Compliance, visit the website:  
<https://uk.soundcore.com/pages/psti-related>.

Note: The 'x' of SN Code: xxxxxxxxxxxxxxxx is a variable, see below table.

| Variable 'x'    | Range of variable | Content                                                                                                   |
|-----------------|-------------------|-----------------------------------------------------------------------------------------------------------|
| Seventh         | 0-9 or A-F        | Denotes the hardware version which is not effected on the safety compliance.                              |
| Eighth          | 8,9,A,B,C...      | Denotes the year, 8 means 2018, 9 means 2019, A means 2020, B means 2021, C means 2022, and so on.        |
| Ninth and tenth | 01,02,03...       | Denotes weeks, 01 means the first week in this year, 02 means the secondary week in this year, and so on. |
| Eleventh        | 1-7               | Denotes date, 1 means Monday, 2 means Tuesday..., 7 means Sunday and so on.                               |
| The last five   | 00001-99999       | Denotes serial No.                                                                                        |

1. Power consumption in standby mode:  $\leq 0.5W$

2. Power management:  $\leq 20min$

3. Information of applicable adapter:

Brand: ANKER

Manufacturer: Anker Innovations Limited

Model: A2337

Input: 100-240V~1.0A, 50-60Hz

Output: 5.0V = 3.0A, 15.0W / 9.0V = 3.0A, 27.0W / 12.0V = 2.5A, 30.0W / 15.0V = 2.0A, 30.0W / 20.0V = 1.5A, 30.0W (30.0W Max)