


## Checking the Battery Level




- ① Trickle-Charging Mode
- ② Recharging
- ③ Remaining Battery Percentage
- ④ USB-C Cable
- ⑤ USB-C Port
- ⑥ USB-A Port
- ⑦ Power Button


## Charging Your Devices

Charge your phones and tablets via the built-in USB-C cable or USB ports.

With the built-in USB-C cable:




With the USB ports:




## Recharging Your Power Bank

Recharge the power bank via the built-in USB-C cable or USB-C port.




## Trickle-Charging Mode


1. Press the power button twice to activate trickle charging mode.



2. Charge your earbuds or other low-power devices via the USB-A port.



3. Press the power button twice to exit trickle charging mode.



Specifications

|               |                                                                                                                                                                                 |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cell Capacity | 20,000 mAh                                                                                                                                                                      |
| Input         | USB-C Cable / USB-C Port: 5V ≍ 3A / 9V ≍ 3A / 12V ≍ 2.5A / 15V ≍ 2A (30W Max)                                                                                                   |
| Output        | USB-C Cable / USB-C Port: 5V ≍ 3A / 9V ≍ 3A / 10V ≍ 2.25A / 12V ≍ 3A / 15V ≍ 3A / 20V ≍ 2.25A (45W Max)<br>USB-A Port: 5V ≍ 3A / 9V ≍ 2A / 10V ≍ 2.25A / 12V ≍ 1.5A (22.5W Max) |
| Total Output  | 5V ≍ 3A (15W Max)                                                                                                                                                               |

