


OVERVIEW





1. Touch Control Area
2. Ear Fin
 - Size 1 ear fins are pre-installed on the earbuds.
3. Ear Tip
 - M-size ear tips are pre-installed at the time of purchase.
4. Earbud Charging Contacts
5. LED Light Strip
6. USB-C Charging Port
7. Charging Case Button


POWERING ON AND PAIRING



- Before using the earbuds, remove all protective films and stickers from the earbuds and the charging case.



Android 6.0+




1. Open the charging case. The earbuds will power on and enter pairing mode automatically.
2. Select "**Anker Liberty Buds 2**" on your device's Bluetooth list to connect.
3. When connected, the LED indicator on the charging case will light up in white for 5 seconds.


Google Fast Pair Supported: Android users can enjoy instant pairing with Google Fast Pair (Android 6.0+).

WEARING GUIDE


1



2



3



Properly wearing your earbuds will provide a more comfortable and stable fit while ensuring optimal noise cancellation and sound quality.

1. Try different ear tips and fins to find your best fit.

How to choose the right ear tips and fins?


Begin with the pre-installed Size 1 ear fins and Size M ear tips. After wearing them correctly:

- a. If the pre-installed eartips cause pressure or discomfort, switch to Size S or other smaller sizes; If the earbuds don't seal well or feel loose, please try using larger size of eartips.
 - b. With the Size 1 ear fins, if the earbuds **cause noticeable pressure or discomfort, please try using the Size 0 ear fins. If the earbuds feel loose in your ears, you could switch to larger sizes to increase stability.**
 - You could use different sizes of ear fins or eartips for each ear, such as Size S for the left ear and Size M for the right.
2. Check the L (left) and R (right) markings on the earbuds before wearing them to avoid confusing the left and right sides.
3. Gently place the earbuds into your ear canal and rotate them for a snug fit.
4. Take a fit test in the app (Go to **Settings > Fit Test**) to ensure you get the best active noise cancelling performance.



- When wearing the earbuds, avoid touching the area near the logo to prevent accidental touches.
- Dust, earwax, or other debris can accumulate in the earbuds. To maintain optimal sound quality, clean them regularly. Use a slightly moistened cotton swab with rubbing alcohol to gently wipe the metal mesh filter beneath the rubber ear tips. Make sure the alcohol has completely dried on the metal mesh filter before using the earbuds again.

CHARGING



1. Place the earbuds in the charging case and close it.
 - Ensure the earbuds and the USB-C charging port are completely dry before charging to prevent damage.
2. Connect the charging case to a power supply using the provided charging cable. For wireless charging, place the charging case at the center of your wireless charger.
 - Use only certified, standards-compliant chargers and cables for charging.
 - Recharging the charging case with the earbuds removed takes 3 hours via cable. A 10-minute charge of the earbuds provides 4 hours of playtime.

Battery Life (Earbuds / with Charging Case)

- Normal mode: 12 hours / 46 hours
- ANC On / Transparency mode: 7 hours / 27 hours
- ANC + LDAC (660 kbps): 4.5 hours / 17.5 hours
- ANC + Calling: 4 hours / 15.5 hours

CONTROLS

Touch Control Area




Touch Control Area

Tap the control area on the earbud to manage different functions.

		Using Dual Earbuds	Using Single Earbud
	Play / Pause Audio	Double Tap (R)	Double Tap
	Play the Next Track	Double Tap (L)	/
	Answer a Call / End a Call	Double Tap (L/R)	Double Tap
	Reject an Incoming Call / Change ANC Mode During a Call	Tap and Hold for 2 Seconds (L/R)	Tap and Hold for 2 Seconds
	Note: To change ANC mode via touch controls, update the earbuds' firmware to the latest version.		
	Switch Between ANC and Transparency Modes	Tap and Hold for 2 Seconds (L/R)	Tap and Hold for 2 Seconds

Charging Case Button




Function	Action
Check Battery Level	Press Once
Enter Pairing Mode	Press and Hold for 3 Seconds (Case Open)
Reset the Device	Press and Hold for 10 Seconds (Case Open)

DUAL CONNECTIONS


Dual Connections is enabled by default. You can connect your earbuds to two Bluetooth devices at the same time using either of the following methods.

Method 1: Using the Earbuds



1. Make sure the earbuds are already connected to the first device.
2. Tap and hold the touch control areas on both earbuds simultaneously for 3 seconds to enter Bluetooth pairing mode, then connect to your second device.

Method 2: Using the Charging Case Button



1. Ensure the earbuds are connected to the first device and placed in the charging case.
2. With the lid open, press and hold the case button for 3 seconds until the LED indicator flashes white, indicating that the earbuds are in pairing mode.
3. On your second device, select "Anker Liberty Buds 2" on the Bluetooth list to complete pairing.

Method 3: Use the App

On the main interface of the app, go to **Settings > Dual Connections > Connect New Device**.



- If your earbuds are already connected to two devices, disconnect from at least one before pairing with a new device.
- Dual Connections can be turned off in the app. Tap the gear icon in the upper-right corner to access Settings, then tap the toggle switch for Dual Connections to turn it off.

AMBIENT SOUND

You can select from the following ambient sound modes in the app:

Noise Cancellation (Level 1 to Level 5)

Adjust the strength of noise cancellation to match your environment. The earbuds feature ear-canal adaptive ANC that automatically adjusts to your ear shape for optimal noise reduction.

Adaptive

Experience seamless sound with Adaptive Noise Cancellation that intuitively tunes to your environment, preserving the perfect harmony between clarity and awareness.


Normal

Enjoy balanced sound without noise cancellation.

Transparency

Stay aware of your surroundings while listening to music.

SOUND EFFECTS



The app offers a range of preset EQ modes designed to match different listening preferences. Each preset EQ mode is carefully tuned to bring out distinct sound characteristics.

Anker Signature (default): Suitable for various music styles and delivers pleasant listening experience.

Clear Vocals: Suitable for podcast, audiobooks, and music.

Powerful Bass: Suitable for hip-hop, rock, electronic, and dance music.

Calm and Soothing: Suitable for classical, jazz, and soothing music.

Anker Balanced: Suitable for pop and blues music.


You can also create your own Custom EQ in the app.

DOLBY AUDIO

Dolby Audio creates an immersive listening experience by placing sound all around you.

• **Music Mode:** Experience immersive 3D sound that enhances your music listening experience with a fixed spatial audio effect.

HearID



HearID intelligently analyzes your hearing sensitivity at different frequencies and creates a personalized sound profile tailored to your unique hearing characteristics.

1. Open the app and go to HearID in the home page.
2. Please sign in to your soundcore account before taking the test. Otherwise, your HearID test results may not be saved.
3. Follow the on-screen instructions to complete the hearing test.
4. Once completed, your personalized EQ profile will be applied automatically.



- During the test, HearID progressively reduces the differences between the A/B audio samples. If you are unable to hear a difference, simply make your best selection and continue.

LDAC

Enable LDAC in the app to enjoy high-resolution audio on devices running Android 8.0 or later. LDAC delivers higher sound quality but increases power consumption and shortens playtime. For the best LDAC experience, use it in a low-interference environment to maintain a stable Bluetooth connection. Follow the steps below to enable LDAC:

5. Open the app and go to Settings.
6. Tap "Sound Mode".
7. Select "Preferred Audio Quality" to switch to the LDAC codec.
8. Tap "Agree" to continue.
9. Switching audio codecs takes about 10 seconds. You may be prompted to update the earclip firmware if an update is available.



- LDAC and Spatial Audio cannot be used at the same time.

AI TRANSLATION

Note: Feature paths and interface visuals may change with software updates. For the most accurate guidance, please refer to your latest app version.


Before Use:

- Update the soundcore app to the latest version and ensure your earclips are connected to the app.
- Disable Dual Connections.

Real-Time Translation

In settings where you're exposed to content in a foreign language for extended periods (e.g., lectures, classes), real-time translation delivers continuous text display and audio playback of the translated content with almost no lag.


In the soundcore app, go to **Anka** page and tap **Real-Time Translation**. Make sure your earclips are connected to the app.



1. Tap **Real-Time Translation**.
2. Tap the language section at the top of the page, then select **Their Language** and **My Language**.
3. Tap the microphone button to start recording.

Face-to-Face Translation

In the soundcore app, go to **Anka** page and tap **Face-to-Face Translation**.



When your earclips are connected to the app, follow the steps below to try out Face-to-Face Translation.


1. Tap the language section at the top of the page, then select **Their Language** and **My Language**.
2. Tap the bottom-right button and speak to your earclips. The translation will play from your phone.
3. Tap the bottom-left button and speak into your phone. The translation will play from your earclips.

Note: This feature works even if your earclips aren't connected to the app. Just speak into your phone, and the translation will play through its speaker.

LED LIGHT GUIDE

Status	LED Behavior
Open case (0%-20%)	The red light stays on for 5 seconds.
Open case (20%-100%)	The white light stays on for 5 seconds.
Case charging (0%-20%)	The red light pulses slowly.
Case charging (20%-100%)	The white light pulses slowly.
Fully charged	The white light stays on for 5 minutes.
Pairing mode	The white light flashes.
Pairing successful	The white light stays on for 5 seconds.
Resetting	The white light flashes.
Reset successfully	The white light stays on for 5 seconds.
During firmware update	The white light pulses slowly.
Firmware update completed	The white light stays on for 5 seconds.

RESETTING



Reset the earbuds if you experience connectivity issues or functionality problems.

1. Place both earbuds in the charging case and leave the lid open.
2. Press and hold the charging case button for 10 seconds.
3. Upon a successful reset, the LED indicator will stay on for 5 seconds and then go off.



• After resetting, you will need to re-pair the earbuds with your devices.

FIRMWARE UPDATE

You will be informed once a new firmware version is detected when you connect the earbuds to the app. Ensure the earbuds are placed in the charging case and the lid remains open until the firmware update is complete. During the update, ensure the earbuds are being charged and avoid using them.

SPECS

Specifications are subject to change without notice.

Input	5V $\equiv$ 1A
Output	5V $\equiv$ 0.28A (0.14A per port)
Battery Capacity	60mAh $\times$ 2 (Earbuds) 580mAh (Charging Case)
Playtime (with ANC Off)	12 Hours / 46 Hours
Playtime (with ANC On)	7 Hours / 27 Hours
Charging Time	Full Charging Time for Earbuds : 1 Hour Full Charging Time for Charging Case (Wired Charging) : 3 Hours Full Charging Time for Earbuds (Wireless Charging) : 4 Hours
Driver Unit	9.2 mm
Frequency Response	20Hz - 20kHz
Impedance	16 Ω
Waterproof and Dustproof Rating (Earbuds)	IP55
Bluetooth Version	6.1
Bluetooth Range	10m (32ft)

COMPLIANCE INFORMATION

Note: The 'x' of SN Code: xxxxxxxxxxxxxxxx is a variable, see below table.

Variable 'x'	Range of variable	Content
Eighth	0-9 or A-F	Denotes the hardware version which is not effected on the safety compliance.
Ninth	8,9,A,B,C...	Denotes the year, 8 means 2018, 9 means 2019, A means 2020, B means 2021, C means 2022, and so on.
Tenth and Eleventh	01,02,03...	Denotes weeks, 01 means the first week of this year, 02 means the secondary week of this year, and so on.
Twelfth	1-7	Denotes date, 1 means Monday, 2 means Tuesday..., 7 means Sunday and so on.
The last five	00001-99999	Denotes serial No.

Hereby, Anker Innovations Limited declares that this device is in compliance with The Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023. For the Statement of Compliance, visit the website: <https://uk.soundcore.com/pages/psti-related>

Default Open Port: Classic Bluetooth + BLE (Bluetooth Low Energy)

Port Description: After the device is powered on, both Classic Bluetooth visibility (or pairing mode) and BLE broadcasting are automatically enabled, providing Bluetooth pairing (or control) services. The Bluetooth service is disabled when the device is powered off.