


[What's in the Box](#)


[Using Your Product](#)

[Specifications](#)


What's in the Box




Anker SOLIX PS200 Portable
Solar Panel



XT-60 to DC7909 Charging
Cable



Solar to XT-60 Charging Cable





Extension Cable (3m)
(x2)




Important Information

Using Your Product

1. Unfold Anker SOLIX PS200 Portable Solar Panel and its stand. For maximum charge, adjust the solar panel up to 4 angles and align it directly under the sun.



2. Charge your portable power station with the included Solar to XT-60 Charging Cable. The included 3m extension cables can be used to extend the charging cable.



Notes:

- Anker SOLIX PS200 Portable Solar Panel can not store electricity. You will need a portable power station to store power.
- Charging efficiency is subject to sunlight intensity.
- Keep your portable power station away from direct sunlight. Excessive heat may cause damage.
- 200W refers to the power of the solar panel, which is not equal to the actual power of the output ports. There will be some power loss when solar energy is transferred into electrical energy, so the actual power of the output ports will be less than the power of the solar panel.

Specifications

Peak Power	200W
Rated Voltage	48V
Rated Current	4.16A
Dimension(Folded)	21.9 × 23.9 × 2.0 in / 557 × 608 × 50 mm
Dimension (Unfolded)	82.0 × 23.9 × 1.1 in / 2084 × 608 × 28 mm
Net Weight	7.4kg / 16.31lb