


Checking Your Battery Level




Charging Your Devices


The wireless charging function is compatible with:

iPhone 16 / 15 / 14 / 13 / 12 Series


AirPods 4 / 3 / Pro 2 / Pro




Charge your phones and earbuds via the USB-C port.



Recharging Your Power Bank



Simultaneous Charging and Recharging



Specifications

Battery Capacity	5,000mAh at 3.87VDC / 19.35Wh
Input	USB-C Port: 5V ≡ 3A / 9V ≡ 2.22A (20W Max)
Output	USB-C Port: 5V ≡ 3A / 9V ≡ 2.22A (20W Max)
Wireless Output	5W / 7.5W / 15W Max
Total Output	USB-C: 5V ≡ 2.4A (12W Max) Wireless: 5W Max

FAQ

Charging Stops at 80%?

Your iPhone may stop charging at 80% to protect the battery. This can happen if it gets too warm during charging as part of iOS 17's thermal control strategy. Charging will resume once the device cools down. Moving your iPhone to a cooler area may help.

Why does "Slow Charger" appear on my phone?

To balance charging speed and temperature control, charging power may be automatically reduced when a temperature rise is detected. This helps lower device temperature without significantly affecting charging speed or performance.

With iOS 18, a "Slow Charger" notification may appear when power is reduced as part of the system's software strategy. Charging remains stable and safe, with no negative impact on the iPhone. Please be assured of the product's quality.